

7. Unscrew the self locking cap in the LED without removing it completely and insert the 1.25m plastic fiber into the cap. Now tighten the cap. Remove the ST adaptor from the power meter PD and mount the Bare fiber adaptor - plastic on to the PD. Insert the other end of the plastic fiber to this adaptor. Repeat above experiment but the optical measurement with a plastic fiber and plastic fiber adaptor in Power meter, instead of measuring it was explained in step 3.

Plot the optical power values and what do you see in the plots and what happens to the E-O conversion efficiency?

8.1.5.2 TABULATION

Wavelength of the LED: 850 nm

| S. No. | V _I V | I _f mA | V _{LED} V | P dBm | P ₀ mW |
|--------|---------------------|----------------------|-----------------------|----------|-----------------------|
| 1 | 0.232 | 3.41 | 1.22 | -34.3 | 3.71×10^{-4} |
| 2 | 0.27 | 3.91 | 1.23 | -33.7 | 4.46×10^{-4} |
| 3 | 0.32 | 4.7 | 1.24 | -31.6 | 6.91×10^{-4} |
| 4 | 0.36 | 5.294 | 1.28 | -30.1 | 9.77×10^{-4} |
| 5 | 0.42 | 6.176 | 1.25 | -29.4 | 1.44×10^{-3} |
| 6 | 0.53 | 7.79 | 1.26 | -28.6 | 1.38×10^{-3} |
| 7 | 0.82 | 10.2 | 1.28 | -26.8 | 2.08×10^{-3} |
| 8 | 1.23 | 18 | 1.3 | -25.2 | 3.01×10^{-3} |
| 9 | 1.6 | 23 | 1.32 | -24 | 3.98 |
| 10 | 1.93 | 28 | 1.33 | -23 | 5.01 |
| 11 | 2.35 | 34 | 1.34 | -21.8 | 6.6 |
| 12 | 2.42 | 35 | 1.34 | -20 | 0.01 |
| 13 | 3.04 | 44 | 1.36 | -19.4 | 0.011 |
| 14 | 3.9 | 57 | 1.38 | -18.3 | 0.014 |
| | | | | | |

✓ O/P R/B ✓


8.2.5.1 TABULATION

| S.No. | V_i Volts | I_{LD} mA | V_{10} Volts | P dBm | P_0 mW |
|-------|----------------|----------------|-------------------|----------|-----------------------|
| 1 | 0.558 | 8.2 | 2.329 | -35.6 | 2.15×10^{-4} |
| 2 | 0.574 | 8.4 | 2.368 | -35.4 | 2.88×10^{-4} |
| 3 | 0.60 | 8.8 | 2.38 | -35.0 | 3.16×10^{-4} |
| 4 | 0.636 | 9.35 | 2.39 | -34.5 | 3.54×10^{-4} |
| 5 | 0.76 | 10 | 2.46 | -33.3 | 4.17×10^{-4} |
| 6 | 0.81 | 12 | 2.56 | -32 | 6.3×10^{-4} |
| 7 | 0.96 | 14 | 2.63 | -31 | 7.9×10^{-4} |
| 8 | 1.06 | 15 | 2.71 | -30 | 10×10^{-3} |
| 9 | 1.14 | 16 | 2.74 | -29 | 1.25×10^{-3} |
| 10 | 1.22 | 17 | 2.78 | -29 | 1.58×10^{-3} |
| 11 | 1.29 | 18 | 2.83 | -27 | 1.91×10^{-3} |
| 12 | 1.32 | 20 | 2.85 | -26 | 2.51×10^{-3} |
| 13 | 1.36 | 21 | 2.88 | -25 | 3.16×10^{-3} |
| 14 | 1.38 | 22 | 2.90 | -23.3 | 4.67×10^{-3} |
| 15 | 1.41 | 23 | 2.91 | -21.2 | 7.58×10^{-3} |

8.2.6 EXPERIMENT

8.2.6.1 PROCEDURE

1. Setup the LD module as shown in the figure.
2. Keep the potentiometer at the minimum position. Turn ON the power to the module.
3. Measure the voltage V_i between ground and the point. Calculate the current through the LD I_{LD} which is given as $I_{LD} = V_i/R_1$
4. Now without changing any voltage or the multi-turn post position, measure the optical power output P of the LD. Calculate the power in mW which is given as $P_0(\text{mW}) = 10^{P(\text{dBm})/10}$



Microwave and Optical Communication Lab

Experiment - 8.1

I Pre-Lab Questions

1 How to change the color of LED?

Ans LEDs produce different colors at different wavelength by using various materials which produce light of different colors. These individual wavelengths appear as

2 What are the two different types of LED structures?

- (i) Planar LED
(ii) Dome LED

3 Compare LED, Incandescent bulb, and CFL lamp power for 450, 300 and 1100 lumens of light.

| | LED | Incandescent Bulb | CFL Lamp |
|------|------|-------------------|----------|
| 450 | 4-5 | 40 | 9-13 |
| 300 | 6-8 | 60 | 13-15 |
| 1100 | 9-13 | 75 | 18-25 |

4 What do you know about the spectral width of LED?

Ans Spectral width of LEDs are of the order of 20 nm to 50 nm whereas lasers are of the order of 1-2 nm. Ideally, all the light is emitted in a range of wavelength centered at the peak wavelength their range is calculated spectral width.

5 Give the expression that relates bandgap and wavelength.

Ans The expression is $E = h\nu = \frac{hc}{\lambda}$

6 How does LED differ from a normal PN junction diode?

Ans An LED ~~are~~ consists of a PN junction just like an ordinary semiconductor diode, the only difference is that the PN junction in LED is covered with a transparent material to direct the emitted light from the junction to the outer surface.

II Post-Lab Question

1. What are the specifications of good LED materials?
Soln. The specifications are (i) long life (ii) No fading (iii) Should be indifferent to heat and cold (iv) Should not have breakable glass.

2. What is Lambertian pattern?

Soln. The Lambertian pattern depends on the angle θ inclinc to the normal that is perpendicular to the surface of the source.

3. Discuss about Fiber LED Coupling.

Soln. Fiber LED Coupling is used to take light from one LED and focus it with a small spot, typically a few millimeters in diameter, onto the end of a fiber optic bundle.

4. On what factor does the speed of LED depend on?

Soln. It depends on the energy gap of the semiconductor and reverse bias.

5. What is OLED?

Soln. OLED stands for Organic Light Emitting Diode which the emissive electroluminescent layer is an LED in organic compound that emits light in response to electric current.

6. Given,

$V = 3V$, $I = 1mA$ and 6 LEDs connected in Series.

What is the power generated in this setup?

$$V = IR$$

$$P = IV$$

$$P = 3mW \text{ for 1 bulb}$$

$$\therefore \text{for 6 bulbs, } 6 \times 3mW = 18mW.$$

7. Given $V_{DIP} = 2.0$

$$I = 20 \text{ mA}$$

Find the value of series resistor?

$$V = IR$$

$$R = \frac{V}{I} = \frac{V - V_{DIP}}{I} = \frac{10 - 2}{20 \times 10^{-3}} = 400 \Omega$$

I Pre-Lab Questions - 8.2

1. What are multi quantum well lasers?

Soln Quantum well lasers with multiple quantum wells is a laser diode in which the active region of the device is narrow that quantum confinement occurs in multiple regions.

2. What are the different types of laser modes?

Soln (i) wavelength (ii) Wavelength (iii) pulsed laser (iv) Acoustic (v) Photon

3. Extend (Nd: YAG) LASER:

Soln Neodymium doped yttrium aluminum garnet (Nd: Y₃Al₅O₁₂)

4. Mention the important transition process demonstrated by Einstein for Laser Action.

Soln Einstein postulated that in an excited level an atom makes a radioactive transition to a lower energy either through spontaneous emission or through stimulated emission.

5. In comparison to LED, Laser has 2nm spectral width.

II Post-lab Questions - 8.2

1. When light amplification occurs in LASER?

Soln. The same photons cause stimulated emission in excited state. Increasing another coherent photon, this results in light.

2. What is preferred over laser is preferred over LED in optic fiber.

3. State the threshold conditions for laser oscillations.

Soln. Laser oscillation is possible or the case of pair (2,3) at an electron density and temperature higher than for the other pair (3,4) and (4,5) when the self absorption is negligible.


4. List some of the major advantages of LASER over LEDs.

Soln. Lasers are specified on their optical output power, a 1 watt laser produces 1 watt of light output. In LED, LED are specified by their electrical power consumption. Thus a 1 watt LED consumes 1 watt of electrical power.

5. What are the sources of noise in LASER?

Soln. The spontaneous emission in the gain medium, technical noise, from excess noise of the pump source, from vibrations of laser resonators.

6. Identify LED and laser region of operation with respect to thresholds in diode current vs optical power curve.



(U)

7

$$P_{avg} = P_{peak}$$

$$P_{width} = 1 \text{ nano}$$

$$T_B = 1/f = 1 \text{ msec}$$

$$\text{Width} = E/T$$


$$P_{peak} = \frac{E}{\Delta t} = P_{\text{single pulse}}$$

$$P_{avg} \times T = P_{peak} \times \Delta t$$

$$P_{peak} = \frac{P_{avg} \times T}{\Delta t}$$

$$P_{peak} = \frac{1 \text{ mW} \times 1 \text{ msec}}{1 \text{ nsec}} = \frac{10^{-3} \times 10^{-3}}{10^{-9}} = \underline{\underline{1000 \text{ W}}}$$

LED



EXPERIMENTAL REPORT COVER SHEET

LASER.

